

Service Manual

W400 Series Winch

For Caterpillar 515 and 525

599008W

A Product of
Allied Systems
COMPANY
Sherwood, Oregon USA

Safety Precautions

Observe the following precautions to prevent injury to personnel and damage to equipment.

- Do not operate winch unless tractor is equipped with a rear screen for operator protection against cable breakage.
- Authorized operators only!
- Report damage or erratic operation of the winch immediately.
- Do not stand while operating the tractor or the winch.
- Make sure that instruments and controls are operative before working the unit.
- Do not use control levers or handles as machine mounting assists.
- Do not use control levers or handles as hangers for clothes, water bags, grease guns, lunch pails, etc.
- Do not permit personnel in the control area when working or making checks on the machine.
- Do not allow riders on the machine or load.
- Use extreme care when operating close to other machines.
- Avoid operating near anyone working or standing.
- Do not stand or permit others to stand in a bight (loop) of the cable.
- Do not stand or permit others to stand near the winch or cable when it is under tension.
- Do not work with a damaged cable (broken wire or strands, or a decrease in the diameter of a cable, are warning signs).
- Do not leave the tractor while the winch line is under tension.
- Avoid pulling the hook over the drum and through the throat of the winch.
- Do not anchor a double or two-part line to the winch.
- When not operating the winch, always leave it in neutral with the brake on.
- Never attempt to clean, oil or adjust a machine while it is in motion.
- Use extreme care when removing cable and ferrule from the drum. When the ferrule is released, the cable may spring out with force.

Winch serial number _____

Date put into service _____

TABLE OF CONTENTS

Basic Adjustment & Installation	A
Trouble Shooting Guide	1
Operation of Winch	4
Winch Disassembly.....	5
How to Remove the Cable Drum Cover.....	5
How to Remove the Free Spool Clutch.....	7
How to Remove the Drive Gear for the Cable Drum for All Models.....	10
How to Remove the Pinion Shaft and Brake for All 400 Series Winches.....	11
How to Disassemble the Pinion Sprag for All 400 Series Winches	13
How to Remove the Pinion Shaft for All Models	11
How to Remove the Ring Gear for All Models with Outside Mounted Ring Gear (Ring Gear Next to Ring Gear Cover).....	15
How to Remove the Input Clutch for All W Series Winches.....	16
Disassembly of Control Valve R231200	19
Disassembly of Control Valve R242044	20
Cleaning and Inspection	21
Reassembly of Control Valve R231200	22
Reassembly of Control Valve R242044	23
Reassembly of the Input Clutch for All Models	24
How to Install the Input Clutch Assembly for All W Series Winches	25
How to Install the Input Clutch and Drop Gear Assembly in All WD Series Winches	26
How to Install the Pinion Shaft for All Model Winches	26
How to Assemble the Pinion Sprag for All 400 Series Winches	27
How to Install the Pinion for All Model Winches.....	27
How to Assemble the Ring Gear Mounted Inside the Drum Drive Gear.....	28
How to Assemble the Ring Gear Mounted Outside the Drum Drive Gear	31
How to Install the Pinion Brake	33
How to Install the Cable Drum and Drive Gear.....	35
Assembly of the Free Spool Clutch.....	37
Machine Service After Winch Overhaul	45
Lubrication	45
Pressures.....	46
Hydraulic Requirements.....	47
Sprag Rotation	47
Tooth Contact for Ring Gear and Pinion	48
Torque Specifications.....	50
Oil Seal Sleeve	52
Oil Seal Driver.....	52
Control Valve.....	53
Parts Identification	55
Assembly Instruction.....	61
Power Flow	63


INTENTIONALLY BLANK

Basic Adjustment & Installation

Freespool Drag Adjustment

If the winch cable requires too little effort to pull it from the cable drum, the tension can be adjusted as follows:


- Loosen the lockscrew.
- Tighten the adjusting nut to increase the tension and loosen it to decrease it.
- Tighten the locknut.



SP-10572

Installing Wire Rope

NOTE: Installing the wire rope this way provides a safety break away if the load should fall down a grade as well as a method of holding the cable under normal operation.



SP-10573



WARNING

This break-away feature will help to prevent the machine from being pulled by the load should the load slip down a hillside, but it is imperative that the operator put the winch control lever in the FREESPOOL position immediately to allow the wire rope to unwind from the winch.


Basic Adjustment & Installation

Install the wire rope to the winch drum as follows:


- Remove the access plug from the winch housing.
- Start the machine and put the winch in the FREESPOOL mode.
- Rotate the drum by hand until the two anchor wire holes are in the center of the hole.
- Put the winch in the HOLD mode and return the machine to the SERVICE POSITION.
- Choose a gauge of wire that will insert through the holes.

Note: The following installation steps are for newer winch models:


- Start the engine and rotate the winch drum so that the wire rope ferrule groove in the inside, left hand wall of the drum is at the top, and shut down engine.
- Remove the wire rope retainer plate cap screws and retainer plate from the winch drum.
- Insert the wire rope ferrule into the groove in the drum and hold the wire rope against the drum.
- Install the retaining plate and cap screws to hold the wire rope in place.
- Start the engine and WINCH-IN the wire rope onto the drum.



- Twist the wire ends together against the drum.
- Install the wire rope into the groove between the ends of the wire so that the wire rope ferrule is in the ferrule groove.
- Twist the ends of the wire together to hold the wire rope.
- Start the engine and WINCH-IN the wire rope onto the drum.
- Install the access plug.



J205winchline.eps



SP-10083

TROUBLE SHOOTING GUIDE

For The W 400 Series Winch

The following data is presented as an aid to locating the source of difficulty in a malfunctioning unit. It is necessary to consider pressure delivered by the differential lock system and connecting lines when running down the source of trouble since the proper operation of any unit therein depends greatly on the condition and operations of the others. By studying the principles of operation together with

data in this section, it may be possible to correct any malfunction which may occur in the system.

TROUBLE SHOOTING PROCEDURE BASICALLY
CONSISTS OF TWO CLASSIFICATIONS: MECHANICAL
AND HYDRAULIC.

MECHANICAL CHECKS

Prior to checking any part of the system from a hydraulic standpoint, the following mechanical checks should be made:

1. A check should be made to be sure all control lever linkage is properly connected and adjusted at all connecting points.

2. Check control levers and rods for binding or restrictions in travel that would prevent full engagement. Shift levers by hand at control valve; if full engagement cannot be obtained, difficulty may be in control valve assembly.

HYDRAULIC CHECK

Before checking hydraulic system for pressures and rates of oil flow, it is essential that the following preliminary check be made:

Check oil level in the rear axle. This should be done with oil temperatures of 180 to 200° F. (82, 2-93, 3° C).

DO NOT ATTEMPT THIS CHECK WITH COLD OIL!!

PROBLEM	REASON	REMEDY
The winch does not have enough power.	Low control pressure from differential lock circuit.	Reference CAT Service Manual - Power Train System Operation, test, and adjust.
	There is a leak in the hoses, tubes or fittings. Air is entering the system.	Make a check of the hoses. Repair, replace or tighten them where necessary.
	The input clutch discs are worn.	Replace the disc. Determine cause.
	The freespool clutch is slipping. Oil seals are leaking to the clutch discs.	Replace the oil seals and clutch discs.
	The input clutch is slipping. Pressure at the input clutch is below normal.	Make a pressure check on the transmission, if applicable. Determine the cause of low pressure and correct.
	The input clutch is slipping. The piston seals are damaged and oil does not actuate the clutch.	Replace the inner and outer piston seals.

PROBLEM	REASON	REMEDY
The winch will not pull in the load. Winch operation is slow or uneven.	The clutch oil pressure is low.	Reference CAT Service Manual - Power Train System Operation, test and adjust.
	The hoses are not correctly installed.	Make a check of all hoses and connections.
	There is a malfunction in the control valve.	Make a check of the control valve.
	The pinion sprag is installed backwards.	Remove the sprag, reverse it and install it.
	The discs for the free spool clutch are worn.	Replace the clutch discs.
	The free spool clutch is slipping. Oil seals are leaking oil to the clutch discs.	Replace the oil seals and clutch discs. Discs must be clean and dry to function properly.
	The pinion brake will not disengage.	Make a check of the piston, guide pins and brake disc. Repair or replace parts as necessary.
	The discs for the free spool clutch are installed without the correct shim.	Make a check for the correct shim dimensions. Install the correct shims.
The winch will not hold a load.	The free spool clutch is slipping. The clutch discs are worn.	Replace the clutch discs.
	The free spool clutch is slipping. The oil seals are leaking oil to the clutch discs.	Replace the oil seals and clutch discs. Discs must be clean and dry to function properly.
	The control valve linkage is damaged, worn or incorrectly installed.	Repair or replace the linkage as necessary.
	The hoses from the control valve to the winch are incorrectly installed.	See that the hoses are correctly installed.
	The cable is slipping and will not wind onto the drum.	The ferrule is not fastened to the drum correctly. Install the ferrule in the drum.
	The pinion sprag does not hold.	Remove any foreign matter from the sprag. See if the sprag is assembled correctly.
The winch will not operate in the free spool position.	Clutch oil pressure is low.	Reference CAT Service Manual - Power Train System Operation, test and adjust.
	A leak or restriction in the hose to the free spool clutch.	Make a check for leaks or restrictions in the hose.
	Damaged or worn piston shaft seals in the free spool clutch.	Replace the seals.
	The handle for adjusting free spool tension is too tight.	See if the wear button is in good condition and free. Adjust the handle.

PROBLEM	REASON	REMEDY
<p>The winch will not operate in the free spool position (continued).</p>	<p>The piston assembly for the free spool clutch is not correctly assembled.</p>	<p>See that the drum support is correctly aligned with the clutch piston.</p>
	<p>The control lever will not remain in the free spool position.</p>	<p>Make a check of the detent ball and spring.</p>
	<p>The separator springs are not installed correctly in the piston assembly for the free spool clutch.</p>	<p>Install the springs correctly.</p>
	<p>The discs of the free spool clutch do not move freely.</p>	<p>Make a check of the clutch discs and separator springs.</p>
	<p>Clutch pack end plate out of position (dropped down behind disc hub).</p>	<p>Disassemble and correctly reassemble.</p>
	<p>The discs of the free spool clutch are too tight.</p>	<p>Make a check for the correct quantity of discs. Make a check of the shim dimensions</p>
	<p>The steel clutch discs are magnetic.</p>	<p>Remove the magnetic field from the plates.</p>
<p>The oil pressure is low at the input clutch. All other pressures are correct.</p>	<p>There is a leak in the input clutch.</p>	<p>Make a check of the seals for input clutch.</p>
	<p>Restriction in input clutch supply line.</p>	<p>Remove line and inspect.</p>
	<p>The control valve is not functioning correctly.</p>	<p>Adjust or repair the valve or linkage.</p>

OPERATION OF THE WINCH

The **ALLIED** winch is mechanically driven. Several hydraulic and mechanical components control the operation of the winch.

The "Input Clutch" delivers engine power to the cable drum through all other winch drive components.

The "Pinion Brake" stops the drum from rotating after you wind in the cable without a load. This feature allows better drum control.

The "Pinion Sprag" holds the load in conjunction with the free spool clutch; this prevents reverse rotation of the drum.

The "Free Spool Clutch" separates the drum from all other drive components. This permits the cable to unwind freely.

The operator controls the winch through a single lever and control valve with three positions.

The "winch in" position permits the valve to actuate the "input clutch". For the purpose of safety, the lever will not remain in the "winch in" position when released by the operator.

The "neutral" or center position actuates the pinion brake.

The "free spool" position permits the valve to actuate the free spool clutch and release the drum to rotate freely. This position includes a detent which holds the lever in the free spool position when released by the operator. This feature permits the operator to get off the machine and pull the cable off the drum.

NOTES

MAINTENANCE AND SERVICE

The instructions contained herein cover the disassembly and reassembly of the winch in a sequence that would normally be followed after the unit has been removed from the machine and is to be completely overhauled.

CAUTION: Cleanliness is of extreme importance and an absolute must in the repair and overhaul of this unit. Before attempting any repairs, the exterior of the unit must be

thoroughly cleaned to prevent the possibility of dirt and foreign matter entering the mechanism.

NOTE: Before disassembly of the winch, determine if the winch has counterclockwise input rotation or clockwise input rotation as viewed from the input side of the winch.

DISASSEMBLY

HOW TO REMOVE THE CABLE DRUM COVER.




Figure 1

Input side of a W400 series winch.




Figure 3

Remove the drain hose assembly and the bearing cap.




Figure 2

Winch from the right side of the machine.




Figure 4

Remove the wear button from the cable drum cover.




Figure 5

Remove the lock type oil sealing ring from shaft.




Figure 6

Remove the snap ring that holds the bearing.




Figure 7

Remove the capscrews that hold the cable drum cover. Use a pry bar to pull the cover 3/8" (9.4 mm) away from the winch housing.



Figure 8

Give support to the cable drum with a hoist and chain or cable. Push the cover back in place so you can see the snap ring around the bearing. Remove the bearing with two pry bars or a bearing puller tool.




Figure 9

Remove the cable drum cover.

HOW TO REMOVE THE FREE SPOOL CLUTCH.

DANGER: The free spool clutch is under approximately 10,000 lbs. (4,600 kg.) of force. Use caution and follow these instructions when you remove or disassemble this component. Incorrect procedure will cause personal injury.




Figure 10

Loosen each capscrew for the free spool assembly one turn at a time until the support plate is 1/2" (12.5 mm) away from the cable drum. See if there is spring tension in the free spool assembly. NOTE: Some free spool clutch housings will have 8 bolts like the one shown and some will have 15 bolts. Use extreme caution on either housing.

DANGER: Spring tension can mean a broken clutch shaft or split rings. Removal of all existing capscrews can release the pressure in the free spool clutch causing personal injury.

If there is no spring tension, and the free spool assembly is loose on the capscrews, remove the capscrews. **IF THERE IS SPRING TENSION, STAND TO ONE SIDE OF THE WINCH AND REPLACE THE EXISTING CAPSCREWS, ONE AT A TIME, WITH CAPSCREWS TWICE AS LONG. AFTER YOU INSTALL ALL THE LONGER CAPSCREWS, LOOSEN EACH, ONE TURN AT A TIME, AND REMOVE THEM.**




Figure 11

Remove the free spool piston assembly.




Figure 12

Remove bore plug retainer ring. Apply low pressure air to the small radial hole next to the oil sealing ring groove on the opposite end of the piston shaft. This will remove the bore plug and "O" ring.




Figure 13

Put a cylindrical spacer inside the bore between the piston and the press bed. The spacer must be 2 to 2.5 in. (5 to 6 cm.) thick and 7.5 in. (19 cm.) in diameter. You can make a spacer from brass or hardwood. Use the press to slowly apply pressure on the drum support plate. Increase the pressure until the drum support passes the split rings.




Figure 14

Remove the split rings. Slowly decrease pressure on drum support plate.




Figure 15

Split ring removed.




Figure 16

Tension released on the free spool piston assembly.




Figure 17

Remove the inner and the outer springs.




Figure 18

Remove the clutch piston from the clutch shaft and the plate assembly.




Figure 21

Remove the drum and the hub support from the winch housing. Remove the hub carefully in a straight line.




Figure 19

Remove the disc hub snap ring from the shaft.




Figure 22

Remove the assembly that gives support to the drum hub.




Figure 20

Remove clutch disc hub, clutch discs and separator springs in the channels of the clutch disc teeth.

HOW TO REMOVE THE DRIVE GEAR FOR THE CABLE DRUM FOR ALL MODEL WINCHES.




Figure 23

Remove bolts and washers from cable drum support. Put puller bolts into the two threaded holes. Remove the drum support.




Figure 24

This is the drum drive gear with the ring gear shown on the inside of the drive gear.




Figure 25

Remove the drum shaft cover and bearing snap ring. Push the shaft through the bearing and the drive gear. You cannot remove the drive gear without removing the inside mounted ring gear as shown in Fig. 24. On

an outside mounted ring gear, proceed to Fig. 26. On an inside mounted ring gear, see Steps 1 and 2.

STEP 1. Remove two bolts holding the ring gear shaft to ring gear cover. Remove stud nuts and bolts holding ring gear cover to winch housing. Using pry slots provided, remove ring gear cover and shims. Wire shims to cover for reassembly.

STEP 2. From outside (ring gear cover side), drive the ring gear shaft out of ring gear. **NOTE:** Use a brass bar a little longer than the ring gear shaft to hold the ring gear inner taper bearing in place. With pinion moved as explained in Figures 31 thru 36, lower ring gear to the bottom the case as far as it will go.




Figure 26

Remove the drive gear and its shaft. Remove the bearing to shaft retainer ring. Remove the shaft outer bearing and drive gear.




Figure 27

Cable drum drive shaft and inner bearing.

HOW TO REMOVE THE PINION SHAFT AND BRAKE FOR ALL 400 SERIES WINCHES.




Figure 28

Use two screws in the threaded holes to pull the outer race a small distance from the housing.



Figure 29

Remove the split shim packs and tag them separately.




Figure 30

Remove pinion drive gear cover and gasket.




Figure 31

Remove pinion shaft piston and cover.




Figure 32

Remove the brake disc.




Figure 33

Remove the brake housing and split shim pack.




Figure 34
Remove the pinion shaft nut.




Figure 35
Remove the disc hub and nut from the pinion shaft.

HOW TO DISASSEMBLE THE PINION SPRAG FOR ALL 400 SERIES WINCHES.




Figure 36

See Figures 28 and 29. Remove the pinion sprag assembly. **NOTE:** On units that have an inside mounted ring gear (as shown in Fig. 24), tap the pinion from inside the ring gear area as far as it will go. This will allow clearance to remove ring gear as explained in Fig. 25 - Step 2.




Figure 37

Remove the front bearing cup.




Figure 38

Make a note of the direction the inner race rotates when the outer race is stationary.




Figure 39

Remove the front bearing cone.




Figure 40

Remove the sprag retainer.




Figure 41

Remove the sprag, the inner race of the sprag, and the rear bearing cone.




Figure 42

Remove the rear bearing cup.




Figure 45

Hold the pinion drive gear. Remove the pinion shaft and its bearing assembly through the ring gear opening.



Figure 43

This is the inner race of the sprag with the front and rear bearing cones.




Figure 46

Remove the pinion shaft drive gear.

HOW TO REMOVE THE PINION SHAFT FOR ALL MODEL WINCHES. NOTE: Ring gear and ring gear cover must be removed before pinion can be removed.




Figure 44

Tap the pinion shaft carefully with a soft headed mallet to push it through the drive gear. Do not damage the shaft.

HOW TO REMOVE THE RING GEAR FOR ALL MODEL WINCHES WITH OUTSIDE MOUNTED RING GEAR. (RING GEAR NEXT TO RING GEAR COVER)




Figure 47

Remove the screws from the ring gear cover. Use pry bars in the pry slots to pull the assembly from the housing. Approximately 1/2 gallon (2.77 liters) of oil will flow out of the opening.




Figure 48

Remove the ring gear and cover from the housing.




Figure 49

Loosen the two bolts in the cover approximately 1/2 in. (1.27 cm.). Hold the cover. Tap the screw heads carefully to overcome the friction caused by the o-rings.




Figure 50

Cover and bearing adjustment shims. Fasten the shims together with wire.




Figure 51

Support the ring gear assembly. Tap the shaft out carefully with a brass rod and hammer. This is the ring gear assembly with the shaft and bearings removed.




Figure 52

Remove the screws as shown. Remove the ring gear.

NOTE: On some models, the ring gear is riveted to the hub. Do not separate them. If damaged, replace with new ring, pinion and hub.

HOW TO REMOVE THE INPUT CLUTCH FOR ALL W SERIES WINCHES.




Figure 53

Remove input clutch housing cap screws and washers.




Figure 54

Loosen the assembly in the housing with pry bars in the pry slots. Remove input clutch, bearing cap and input flange as an assembly.




Figure 55

Remove the piston rings from the shaft.




Figure 56

Remove the snap ring that holds the bearing.



Figure 57

Remove the bearing from the shaft.




Figure 58

Remove the inner snap ring.




Figure 59

Remove the input gear and its bearing from the shaft.




Figure 60

Remove the clutch disc backing plate retainer ring. Remove backing plate.




Figure 61

Remove the inner and outer clutch discs.




Figure 62

Remove the inner bearing with a bearing puller tool.



Figure 63

Compress the return spring and remove the snap ring. Remove the spacer, spring retainer, spring and piston assembly. NOTE: Some units will not have a spacer.

CAUTION: Be careful when you remove the snap ring and release spring. The spring is under compression.




Figure 64

Remove the nut, washer and "O" ring from the pinion shaft. Remove input flange.




Figure 67

Remove the input clutch shaft bearing cap.




Figure 65

Remove the input shaft and clutch drum.




Figure 68

Remove the one-way check valve breather from the winch housing. (Breather not as shown.)




Figure 66

Input shaft and clutch drum removed from clutch housing.

**DISASSEMBLY OF THE CONTROL VALVE.
R231200**

NOTE: There are two types of control valves. They are basically the same. See pages 53 and 54 for cross sections.




Figure 69

Control valve assembly. See page 53 and page 54 for control valve part identification.




Figure 70

Remove the bolts that fasten the cover to the valve body.




Figure 71

Remove the detent spring and ball.




Figure 72

Remove the oil seal with a pointed tool. This procedure will damage the seal and it cannot be used again.




Figure 73

Remove the snap ring on the spring washer. Remove the valve spool, spring, spacer and washer.




Figure 74

From the opposite end of the control valve, remove the retaining ring for the valve stop. Remove the valve stop, centering spring, regulating spool, spacer and sleeve.




Figure 75

This is the regulating spool disassembled.




Figure 78

The washer, spacer, spring and retainer on the valve spool can then be removed.

**DISASSEMBLY OF THE CONTROL VALVE
R242044**



Figure 76

Remove the oil seal. This procedure may damage the seal and the seal cannot be used again.




Figure 79

Remove the valve spool as shown.




Figure 77

Remove the snap ring.



Figure 80

The detent spring and ball can then be removed.

CLEANING AND INSPECTION

Clean parts with solvent. Inspect them carefully. Replace all parts showing wear or stress. Early replacement of parts with defects will reduce the chance of failure later.

CAUTION: Solvents can damage skin and eyes. Solvent vapors can damage lungs; solvent vapors are flammable, and a concentration of vapor will burn. Use solvents only in a well ventilated area. Do not smoke while cleaning parts and do not use solvents near an open flame.

BEARINGS

Put bearings in a container filled with solvent. Move them around in the solvent to remove old lubricant and foreign matter. Remove the bearing from the solvent and carefully hit the larger side against a block of wood to remove foreign matter. Do not damage the bearing. Repeat this procedure until the bearing is completely clean.

Dry bearings with air under pressure. Do not spin bearings while drying them.

Make an inspection of rollers, cages and cups for wear or damage. Lubricate bearings with the correct oil and wrap them in clean paper until you are ready to install them.

GEARS AND SHAFTS

Make an inspection of gear teeth and shaft splines for wear or damage. Look for bent shafts. Use the "Magna-flux" process whenever possible to look for cracks. Replace any part with wear through the case hardening.

GASKETS AND OIL SEALS

Replace all gaskets, oil seals, o-rings, snap rings and metal sealing rings whenever you disassemble the winch. Install sealing parts carefully. Any damage to a sealing part will cause it to leak. Put a thin layer of Permatex No. 2 to the outside surface of oil seals before you install them. This procedure will prevent leakage between the seal and its retainer.

Lubricate metal sealing rings with chassis grease to help you install parts more easily. Lubricate all rubber parts with the correct oil before installing them.

HOUSING

Cast parts with polished surfaces can be cleaned with solvent or steam. They must not be cleaned with a hot alkali solution.

Other housings, caps and covers can be cleaned in a hot solution tank until completely heated. Remove all alkali solution from parts with clean water. Dry them immediately with air under pressure or a clean, lint-free cloth.

CAUTION: Alkali solutions and vapor can damage skin, eyes and lungs. Steam will burn skin and eyes.

NOTE: Free spool clutch discs must be flat and not worn. Friction discs must be changed if oily, as cleaning will not remove oil from friction material. Free spool clutch discs must be installed **DRY**.

SEE ASSEMBLY INSTRUCTIONS ON PAGES 60, 61 AND 62.

REASSEMBLY OF CONTROL VALVE. R231200




Figure 81

Install the valve stop, centering spring, regulating spool, spacer and sleeve. Install retainer ring.




Figure 82

Install the valve spool, spring, spacer and washer. Compress spring and install retainer ring.




Figure 83

Apply a light coat of Permatex #2 to the outer diameter of the valve spool oil seal. Install with lip of seal in.




Figure 84

Replace the detent ball and spring.




Figure 85

Replace the bolts that fasten the cover to the valve body. Tighten to specified torque. (See torque chart.)

REASSEMBLY OF CONTROL VALVE R242044




Figure 86

Insert the ball and detent spring into its location in the housing.




Figure 87

Insert the spool into the valve housing.




Figure 88

Slide the washer, spacer, spring and retainer onto the spool.




Figure 89

Compress the spring assembly and install the snap ring.




Figure 90

Apply a light coat of Permatex to the outer diameter of the valve spool oil seal. Install the lip of the seal in.



Figure 91

Install the check valve breather in the winch housing.

REASSEMBLY OF THE INPUT CLUTCH FOR ALL MODEL WINCHES.




Figure 92

Install the lip seal on the input shaft, and the piston ring on the piston.




Figure 93

Install the piston, spring, spring retainer and snap ring.
NOTE: Some units will have a snap ring spacer.




Figure 94

Install the first outer steel disc (teeth on the outer diameter) into the clutch drum.




Figure 95

Install the first inner friction disc (teeth on the inner diameter). Add another steel outer disc followed by another friction inner disc. Alternate discs until the proper amount is installed. You start with a steel disc and end with a friction disc.




Figure 96

Install the clutch disc backing plate and retainer ring.
Install the clutch gear inner bearing.




Figure 97

Install the oil baffle ring in the clutch hub gear.



Figure 98

Install clutch driven gear into clutch drum. Align splines on clutch gear with internal teeth of friction discs. Tap gear into position. Do not force this operation. Gear splines must be in full position with internal teeth of all friction discs.




Figure 101

Install outer bearing and retainer ring. Install piston rings on clutch shaft.

HOW TO INSTALL THE INPUT CLUTCH ASSEMBLY FOR ALL W SERIES WINCHES.




Figure 99

Install clutch gear outer bearing.




Figure 102

Apply a light coat of Permatex #2 to the outer diameter of the input shaft oil seal. Install the seal in the input bearing retainer. Press seal to depth shown on assembly instruction drawing. (Page 60)



Figure 100

Install bearing retainer ring.




Figure 103

Install the front bearing. Install the retainer and bolts. Tighten the bolts to the specified torque. (See torque chart.)




Figure 104

Install the clutch assembly in the clutch housing. Install the input flange, o-ring, washer and nut. Tighten nut 175 to 200 ft. lbs. of torque (25-27 kgf·m, 237-271 N.m.). Install the input clutch and bearing cap assembly on the winch. Install the bolts and tighten 26 to 29 ft. lbs. of torque (3.4-4 kgf·m, 36-39 N.m.).

HOW TO INSTALL THE PINION SHAFT FOR ALL MODEL WINCHES.




Figure 105

Install inner bearing on pinion shaft.




Figure 106

Install the pinion and drive gear in the winch. All 400 series winches are currently manufactured with spacer between the pinion inner bearing and drive gear. **NOTE: IF PINION IS MATCHED WITH A RING GEAR THAT IS MOUNTED ON THE INSIDE OF THE CABLE DRUM DRIVE GEAR (AS SHOWN IN FIG. 24) DO NOT PROCEED ANY FARTHER WITH THE PINION INSTALLATION UNTIL THE RING GEAR IS INSTALLED.**

HOW TO ASSEMBLE THE PINION SPRAG FOR ALL 400 SERIES WINCHES.




Figure 107

Install the rear bearing cone in the sprag outer race.




Figure 108

Install the rear bearing cone and sprag inner race.




Figure 109

Install the sprag assembly and retainer in the outer race.




Figure 110

Install the front bearing cone in the outer race.




Figure 111

Install the front bearing cup in the outer race.

See note in Fig. 106.




Figure 112

Make a check that the sprag turns in the correct direction. If you did not make a note of the direction of sprag rotation during disassembly, see the chart on page 47.

HOW TO INSTALL THE PINION FOR ALL MODEL WINCHES. NOTE: Some models will have taper bearings instead of ball bearings. SEE NOTE IN FIGURE 106.




Figure 113

Position new "O" rings on the sprag outer race. Install the sprag assembly on the pinion shaft.




Figure 114

Install the shims on the outer race of the sprag. These shims affect the tooth contact between the ring and pinion gears.




Figure 115

Install the disc hub, washer and nut.




Figure 116

Put a block under the pinion gear to prevent it from turning. Tighten the pinion shaft nut 175 to 200 ft. lbs. torque (2.0-2.3 kgf·m, 237-271 N.m.).

HOW TO ASSEMBLE THE RING GEAR MOUNTED INSIDE THE DRUM DRIVE GEAR. (LIKE SHOWN IN FIGURE 24)




Figure 117

Assemble the ring gear and hub. Tighten the bolts to specified torque. (See torque chart.)




Figure 118

Position the inner tape bearing on ring gear shaft. Install shaft and bearing in ring gear. Install outer bearing.




Figure 119

Measure the distance from the inner race of the bearing to the end of the shaft. Make a note of this distance.




Figure 120

Measure the distance from the face of the cover to the bottom of the bore. Make a note of this distance. Subtract the distance from the inner race to the end of the shaft from this distance. Subtract .005 inch (.1270 mm) from the difference.

EXAMPLE: If the first distance is .740 inch (18.79 mm) and the second distance is .801 inch (20.32 mm), the difference is .061 inch (1.53 mm). Subtract .005 inch (.1270 mm) and the answer is .056 inch (1.4 mm). You need shims with a total thickness of .056 inch (1.4 mm).




Figure 121

Install selected shims between ring gear shaft and ring gear cover. Install cover to shaft bolts and washers. Tighten bolts to specified torque. (See torque chart.)

Install ring gear cover in a vise equipped with soft jaws as shown in Figure 122.




Figure 122

Use a cord and scale to find the preload tension on the bearing. Tie a cord around the splines on the gear as shown. Fasten the end of the cord to the scale. Pull the scale away from the gear. Make a note of the number shown by the scale when the assembly begins to rotate. The scale must show between 19.5 lbs. and 23 lbs. (8.8-10.4 kg). This equals 50-60 lbs./in. (0.57-0.69 kgf/m, 5.64-6.77 N.m.) preload tension on the bearing.

If the scale shows less than 19.5 lbs. (8.8 kg), remove shims. If the scale shows more than 23 lbs. (10.4 kg), add shims. See Steps 1 and 2.

STEP 1. After proper preload on taper bearings is made, remove ring gear cover and shims. Remove ring gear shaft and taper bearings.

STEP 2. Position the inner taper bearing in the inner taper bearing cup in the ring gear. (This is the bearing and cup on the inside next to the ring gear.) Hold bearing in place with a loose fitting rod or bar through inner ring gear shaft bore.

Position ring gear inside the pinion. Insert ring gear shaft from inside cable drum housing making sure inner bearing remains in inner bearing cup. Tap shaft into position in housing. Continue to install the pinion sprag as explained in Figure 113 thru Figure 116. Position ring gear shaft outer bearing on shaft. To facilitate assembly of the ring gear cover and pre-selected shims, install two aligning studs in the end of the ring gear shaft. Position pre-selected shims on studs. Align studs with holes in cover.




Figure 123

Position the ring gear cover on housing to cover studs leaving enough space to install ring gear cover to housing shims. Use the same shims or equivalent thickness shims that were removed at disassembly. Position shims under ring gear cover. Install cover with inspection hole plug in location shown (about 11 o'clock). Install bolts, washers and stud nuts. Tighten bolts and nuts to specified torque. (See torque chart.)

Remove one aligning stud from ring gear shaft and install one cover to shaft bolt and washer. Remove other stud and install bolt and washer. Tighten bolts to specified torque. (See torque chart.)




Figure 124

Fasten an indicator in the position shown in the

photograph. Hold the pinion so that it cannot move. From the drum side of the housing as shown, rotate the ring gear assembly in a clockwise direction until it stops against the teeth of the pinion. Place the end of the indicator stem against the face of a tooth of the ring gear. It must rest at 90° to the tooth face. Adjust the indicator to show zero. Rotate the ring-gear in a counter-clockwise direction until it stops against the teeth of the pinion. Make a note of the number shown by the indicator. It must show between .006 and .011 inches (.152 and .249 mm). See the tooth contact chart on pages 48 and 49.

If the indicator shows more than .011 inches (.279 mm) add shims between the ring gear cover and the winch housing. If it shows less than .006 inches (.152 mm) remove shims.

Paint the teeth of the ring gear with a mixture of red lead and linseed oil. Rotate the pinion against the ring gear. Make a check of the tooth contact as shown by the red lead. See the tooth contact chart on pages 48 and 49. Add or remove shims from between the outer race of the pinion sprag and the winch housing or ring gear cover to housing shims to adjust tooth contact. Repeat this procedure until tooth contact is correct.

After pinion bearing preload, ring gear backlash and ring gear to pinion tooth contact is set, use following procedure:

Remove two bolts holding the ring gear shaft to ring gear cover. Remove stud nuts and bolts holding ring gear cover to winch housing. Using pry slots provided, remove ring gear cover and shims. Wire shims to cover for reassembly.

From outside (ring gear cover side A) drive the ring gear shaft out of ring gear. NOTE: use a brass bar a little longer than the ring gear shaft to hold the ring gear inner taper bearing in place. With pinion moved as explained Figures 30 thru 35, let ring gear drop to the bottom of the case as far as it will get but keep inner bearing in place in inner cup.

Position the cable drum drive gear in the housing with long hub of gear in toward outside (rear) bearing bore. See assembly instructions on page 60 for position of drive gear hub for inside mounted ring gear. Use a bar or rod through outside bearing bore and into cable drum area. Use a chain and hoist and pull drive gear up as far as it will go against the top of the winch housing.

Repeat procedure explained after Figure 122 - Step 2 and Figure 123.

After ring gear and pinion are fully reassembled, lower cable drum drive gear in position on ring gear. Install inner (front) bearing on drive shaft as shown in Figure 27.

Remove chain and bar from drive gear. Insert shaft and bearing thru drive gear into outer (rear) bearing bore. Block shaft from inside and install rear bearing on drive shaft. Install rear bearing locating ring into winch housing. Proceed with Figure 135.

HOW TO ASSEMBLE THE RING GEAR MOUNTED OUTSIDE THE DRUM DRIVE GEAR.




Figure 125

Assemble the ring gear and hub. Install ring gear bolts. Tighten bolts 40 to 60 ft. lbs. of torque (5.53-8.29 kgf·m, 54.23-81.35 N.m.).




Figure 126

Position the inner taper bearing on ring gear shaft. Install shaft and bearing in ring gear. Install outer bearing.




Figure 127

Measure the distance from the inner race of the bearing to the end of the shaft. Make a note of this distance.




Figure 128

Measure the distance from the face of the cover to the bottom of the bore. Make a note of this distance. Subtract the distance from the inner race to the end of the shaft from this distance. Subtract .005 inch (.1270 mm) from this difference.

EXAMPLE: If the first distance is .740 in. (18.79 mm) and the second distance is .801 in. (20.32 mm), the difference is .061 in. (1.53 mm). Subtract .005 inch (.1270 mm) and the answer is .056 inch (1.42 mm). You need a shim with a thickness of .056 inch (1.42 mm).




Figure 129

Install selected shims in cover.




Figure 130

Assemble the ring gear cover to the shaft with bolts and washers. Tighten to specified torque. (See torque chart.)




Figure 132

To check ring and pinion gear for proper tooth contact, paint ring gear teeth with a mixture of red lead and linseed oil. When ring and pinion gears are rotated, the red lead is squeezed away by the contact of the teeth, leaving bare areas the exact size, shape and location of the contacts. As a rule, painting about 10 or 12 teeth is sufficient for checking purposes.




Figure 131

Use a cord and a scale to find the preload tension on the bearing. Wind a cord around the splines on the gear as shown. Fasten the end of the cord to a scale. Slowly pull the scale away from the gear. Make a note of the number shown by the scale when the assembly begins to rotate. The scale must show between 19.5 lbs. and 23 lbs. (8.8 and 10.4 kg). This equals 50-60 lbs.-in. (0.57-0.69 kgf·m) preload tension on the bearing. If the scale shows less than 19.5 lbs. (8.8 kg), remove shims. If the scale shows more than 23 lbs. (10.4 kg), add shims.

With new "O" ring installed on ring gear cover, position the ring gear cover on housing to cover studs leaving enough space to install ring gear cover to housing shims. Use the same shims or equivalent thickness shims that were removed at disassembly. Position shims under ring gear cover. Install cover with inspection hole plug in location shown (about 11 o'clock). Install bolts, washers and stud nuts. Tighten bolts and nuts to specified torque. (See torque chart.)




Figure 133

Remove the check plug from the ring gear cover. Rotate ring gear assembly in a clockwise direction until a bolt, rivet or counter sunk hole appears in the plug hole.




Figure 134

Hold the pinion so it cannot move. Move the ring gear assembly in a clockwise direction until it stops against the teeth of the pinion. Fasten an indicator in the position shown in the photograph. Put the right angle adapter for the indicator at an angle of 90° against the side of the nut or rivet. Adjust the indicator to zero. Move the ring gear assembly in a counter-clockwise direction until it stops against the teeth of the pinion. Make a note of the number shown on the indicator. It must show between .006 and .011 inches (.15 and .28 mm). If the indicator shows more than .011 inches (.28 mm), remove shims from between the ring gear cover and the winch housing.

If it shows less than .006 inch (.15 mm), add shims.

Rotate ring gear and pinion. Check tooth contact pattern on drive side (convex side) of ring gear teeth. Coast side will automatically be correct when drive side pattern is correct. Refer to gear tooth contact chart. If proper tooth contact pattern is not as shown, readjust backlash or, add to or subtract from shim pack between ring gear cover and winch housing or between the pinion sprag outer race and winch housing.

Addition of or subtraction of shims should be made in small increments until proper contact is established. Split shims are provided to permit removal or insertion. Note: It may be necessary to remove or add shims between the pinion sprag.

HOW TO INSTALL THE PINION BRAKE




Figure 135

Install pinion shaft brake disc housing. Install brake disc.

NOTE: Make sure that the teeth on the brake disc align with the disc hub.




Figure 136

Install the shims behind the housing. Put an inch/lb. (kgf·m) torque wrench on the hub nut. Turn the pinion with the torque wrench. Make a note of the number shown by the wrench when the pinion begins to turn. Install two bolts in the brake housing and tighten them to the correct torque. Put the torque wrench on the hub nut again.

Turn the pinion. Make a note of the number shown by the wrench when the pinion begins to turn. Compare the two measurements. The second measurement must be 15 to 25 lbs.-in. (0.17-0.28 kgf·m, 1.69-2182 N.m.) greater than the first. Add or remove shims to change this measurement. Repeat this procedure until the measurement is correct. Remove two bolts holding the brake disc housing.




Figure 137

Install new brake piston ring expander spring and piston ring on brake piston. NOTE: Expander spring gap to be 180 ° from piston ring hook joint. Install new "O" ring on end cap. Install piston and end cap on brake disc housing. If cast iron ring is used on piston, do not install expander spring.

NOTE: The dowel pins must protrude .188-.250 in. (47.7 mm) beyond the lip of the cover.




Figure 138

Install bolts and washers. Tighten to specified torque. (See torque chart.)




Figure 139

Install the cover and the gasket for the pinion drive gear. Install bolts and washers.




Figure 140

Tighten cover bolts to specified torque. (See torque chart.)




Figure 141

Install the cable drum drive shaft inner bearing on shaft. Install drive gear on shaft with long hub of gear away from inner bearing. Install outer bearing on shaft and bearing to shaft retainer ring.

HOW TO INSTALL THE CABLE DRUM AND DRIVE GEAR




Figure 142

Install the drum drive gear, shaft and bearing assembly in housing. Install bearing locating ring in housing.




Figure 143

With new drive shaft cover gasket and oil tube in place, install cover on housing. Install cover bolts and washers.




Figure 144

Tighten the cover mounting bolts to specified torque. (See torque chart.)




Figure 145

Install cable drum support bearing in support. Install bearing retainer. Coat outer diameter of support oil seal with a light coat of Permatex #2. Install seal in support with lip of oil seal toward bearing. Press seal flush with outer seal bore surface. (See assembly instruction drawing.) Position new "O" ring on support. Install drive shaft inner bearing locating ring in support. Position support on housing and drum drive shaft. Install support to housing bolts and washers.




Figure 146

Tighten the support mounting bolts to specified torque. (See torque chart.)




Figure 147

Install new oil seal wear sleeve on drum hub support as shown on assembly instruction page. Install the drum hub support on the cable drum. **NOTE:** The drum shaft oil seal shown must not be installed until after the cable drum and support is in position on drum shaft. See Fig. 150 and Fig. 151 for oil seal installation. Install drum hub support to cable drum bolts and washers.




Figure 148

Tighten the hub support bolts to specified torque. (See torque chart.)




Figure 149

Position the cable drum and support assembly on the

drum drive shaft and into the winch housing. **Do not install the cable drum to its full position.** When the inner edge of the cable drum is just entering the winch housing, do not install drum on shaft any farther at this time.

Installing the drum to its limit will allow the first inner clutch disc of the drum clutch to fall behind the clutch disc hub and will require disassembly of drum and support from the drive shaft to retrieve clutch disc.




Figure 150

Apply a light coat of Permatex #2 to the outer diameter of the drum release support seal. (A fabricated seal sleeve and driver as shown in Figures 150 and 151 will facilitate support seal assembly.) Position seal on oil seal sleeve with lip of seal in as shown. Install sleeve on cable drum drive shaft. Push seal off sleeve and on drive shaft and up against oil seal bore in support. Remove sleeve.

See Page 52 for support sleeve and seal driver details.




Figure 151

Using a seal driver as shown tap oil seal into position in drum release support.

ASSEMBLY OF THE FREE SPOOL CLUTCH

See your parts list for proper amount of clutch discs.
See note after **Cleaning and Inspection page 21.**




Figure 152

Position clutch disc hub on drum drive shaft. Install disc hub retainer ring.

NOTE: A measurement must be made of the overall free spool clutch disc pack after assembly into cable drum. (See Figure 165) This measurement should be made before the separator springs are installed, then after proper quantity of discs are determined, remove entire clutch pack and reassemble with springs as explained in Figures 153 thru 164.

Some older units did not use separate springs. If springs were not used, install first steel disc, then friction disc and alternate steel and friction until proper amount of discs are installed. Make measurement from last steel disc as explained in Fig. 165.




Figure 153

Install one steel disc with teeth on the outer diameter. NOTE: The steel disc has teeth missing on the outer diameter. This is to allow passage for the clutch disc separator springs. Note location of outer teeth of first steel disc. This is important as the next steel disc installed must be moved one tooth over from the first steel disc. See Figure 164.




Figure 154

Install a friction clutch disc with teeth on the inner diameter.




Figure 155

Rotate a second steel disc one tooth in a counter-clockwise direction from the position of the first steel disc. Install disc.




Figure 156

Install next friction disc. Alternate clutch discs, steel against friction and always align the teeth on each steel disc with the teeth on the preceding steel disc until half of the friction discs are installed. You start with a steel disc and end with a friction disc.




Figure 158

Rotate a steel disc in a clockwise direction one tooth from the position of the last steel disc. The teeth in this steel disc will be in the same channel as the very first steel disc installed and will cover the ends of the separator springs.




Figure 157

Install three separator springs, one after the other, in a clockwise direction. Do not put a spring in the next channel. See assembly instruction page for proper spring location and assembly.

Install three more springs in the following three channels. If assembly is correct, you will have three springs and a space and three more springs and a space. (See assembly instruction page.)




Figure 159

Install one friction disc.




Figure 160

Rotate a second steel disc in a counter-clockwise direction one tooth. Install disc and note location of teeth as explained in Figure 153.




Figure 161

Install next friction disc followed by a steel disc in the same position as the second until all the discs are installed. The last disc must be friction. From the separator springs out, you start with a steel disc and end with a friction disc.




Figure 162

Install three separator springs, one after the other, in a clockwise direction. Do not put a spring in the next channel. (See assembly instruction page.)

Install three more springs in the following three channels. If assembly is correct, you will have three springs and a space and three more springs and a space. (See assembly instruction page.)




Figure 163

Install last outer steel disc rotating disc clockwise one

tooth from position of preceding steel disc. The teeth on this steel disc will be in the same channel as the very first steel disc installed and will cover the ends of the separator springs.




Figure 164

Detail of Separator Spring Installation.




Figure 165

After complete assembly of clutch pack and separator springs, compress clutch pack and springs and measure clutch pack again. Measurement must be within distance explained below.

Measure the distance from the last steel (not as shown - as last disc must be a steel outer disc with teeth covering the separator springs) clutch disc to the outer face of the cable drum. This distance must be between 6.691 and 6.768 inches (169.9-171.7 mm). If it is more or less, make a check that the correct quantity of clutch discs are used. See the free spool clutch disc chart on the assembly instruction drawing. Install another steel disc as a shim to decrease distance, if necessary. NOTE: If another steel disc is used as a shim, be sure the teeth on the steel disc match the teeth on the last steel disc installed and cover the ends of the separator springs.




Figure 166

Install o-rings and lip seals on the clutch shaft and release plate. See Fig. 167 for the correct position of the lip seals.




Figure 169

Position the inner and outer springs on the drum release clutch position. Put a small amount of grease in the split ring grooves to hold split rings after support is compressed.




Figure 167

This is a view of the correct position of the lip seals.





Figure 168

Install the drum release clutch piston on the clutch shaft. Do not install bore plug at this time.



The bolt holes that are centered between the spring bosses must be aligned with timing mark.




Figure 170

Install the cable drum support on the shaft. Align it with the timing mark as indicated in the drawing. Make a check that the springs are centered and are not on the raised bosses.

DANGER - When assembled, the free spool clutch is under approximately 10,000 lbs (4,600 kg) of force. Use caution and follow these instructions when you assemble the clutch. Incorrect procedure will cause personal injury.




Figure 171

Place the assembly in the press as shown. Put a cylindrical spacer inside the drum between the piston and the press bed. The spacer must be 2 to 2.5 inches (5 to 6.5 cm) thick and 7.5 inches (19 cm) in diameter. You can make it from hardwood or brass. Keep the entire bottom surface of the piston drum in contact with the press bed. Use the press to slowly put pressure on the flange part of the drum support. Increase the pressure until the drum support passes the split ring groove.




Figure 172

Put a small amount of heavy grease in the split ring grooves to hold the split rings. Install the split rings. Slowly release the pressure from the clutch assembly so the split rings will center in the grooves.

CAUTION: Be certain split rings are in full position in clutch shaft. Release press **slowly**.

Remove assembly from press. Install new "O" ring on the piston bore plug. Install bore plug in drum release clutch piston. Install bore plug retainer ring.




Figure 173

Install the free spool assembly in the cable drum. The bolt holes in the drum support plate and the drum face must line up directly. If the bolts will not enter the threaded holes in the drum, the drum support plate and the clutch piston are not aligned (timed) correctly. **DO NOT** attempt to twist or pry the piston assembly to align with the holes. Remove and disassemble the piston assembly. Align the drum support plate and piston as explained in Figure 170. Assemble and install the piston assembly and bolts.




Figure 174

NOTE: Some free spool clutch housings will have 8 bolts like the one shown and some will have 15 bolts. Tighten the mounting bolts to specified torque. (See torque chart.)

A check can be made at this time to see if the free spool seals are installed correctly. See Figures 180 and 181 for procedures.




Figure 175

Apply a light coat of Permatex #2 to the outer diameter of the cable drum cover oil seal. Press seal in cover with lip of seal in. Press drum cover outer support bearings in cover.




Figure 176

A bearing driver like the one shown can be made to

facilitate assembly of the cable drum cover and support bearing to the free spool and winch housing. The bearing driver is designed to axially drive against both the inner and outer race of the bearing.




Figure 177

Install two undersize guide studs or rods in the bottom and top winch housing to drum cover threaded holes as shown. Position drum cover, bearing and oil seal on studs as shown. Bearing will slip on support up to bearing retainer ring groove. Using a bearing driver as shown, drive cover and bearing to full position on support. Install cover to winch housing bolts and washers.




Figure 178

Tighten cover bolts to specified torque. (See torque chart.)




Figure 179

Install bearing to free spool hub retainer ring.




Figure 180

You must now make a check to see if all the seals in the free spool clutch are installed correctly. Make the following tests.




Figure 181

1. Put air pressure less than 100 p.s.i. (7,030.70 kgf/cm², 689.4 kpd) to the center hole "A" in the end of the shaft. Air must not come out of radial hole "B".
2. Put air pressure in hole "B". Air must come out of hole "A".
3. Repeat "step 2" and put your finger over hole "A". Air must not come out of any part of the assembly. If the assembly leaks air, disassemble and check seals. See if the seals are damaged or installed backwards.




Figure 182

Install the piston ring on the drum shaft.




Figure 185

Apply a light coat of grease to the adjusting handle threads. Install the free spool adjusting handle and spring. Turn handle so it just contacts spring.




Figure 183

Install the free spool wear button. NOTE: A new wear button is .875 (22,2) thick. When worn to .625 (13,9) replace button.




Figure 186

Install the lock button and the lock spring.




Figure 184

Install the bearing cap and the drain hose. Install bolts and washers. Tighten bolts to specified torque. (See torque chart.)




Figure 187

Install the lock screw and tighten to specified torque. (See torque chart.)

MACHINE SERVICE AFTER WINCH OVERHAUL IF THE WINCH FAILURE CONTAMINATED THE SYSTEM

1. Flush the rear axle oil.
2. Disconnect and clean the winch to axle drain line, differential pump suction line, and lines to the differential filter.
3. Change rear differential filter.
4. Inspect differential pump.
5. Refill axle.

LUBRICATION

The winch is lubricated by the axle powertrain fluid. Refer to Caterpillar's Owners and Operators Manual for oil specifications.

PRESSURES

The following chart shows the correct operating pressures in the winch for each of its operations. The pressure must be taken at a low idle speed with an oil temperature of between 180 ° F (82 ° C) and 200 ° F (93 ° C) or normal operating temperature. All of the pressures listed are "pounds per square inch."

See transmission maintenance and service manual for clutch pressure check procedure.

FUNCTION	PRESSURE LOCATION		
	Free Spool Clutch Pressure	Input Clutch Pressure	Input Brake Pressure
FREE SPOOL	240-280	0	240-280
WINCH IN	0	240-280	0
HOLD	0	0	240-280

HYDRAULIC REQUIREMENT

HYDRAULIC SYSTEMS

1. The winch was originally designed to operate with the hydraulic system on a transmission with pressure at 280 p.s.i. A sample schematic of this circuit is in the back of the winch operator's manual.
2. An alternate hydraulic system was developed to operate the winch using an auxiliary engine mounted pump and the case as its own hydraulic sump. This example is included in the retro-fit packet.

Fluid oil works properly down to -10 ° F. Call **ALLIED** Engineering Department for oils to operate at lower temperatures.

1. Transmission fluid (Dexron I or II) Grade 10, 150 VG 46

LINE SIZES

1. The winch functional supply lines should have a minimum size of 3/8" ID. hose or tubing.
2. The control valve drain lines should have a minimum size of 1/2" ID. hose or tubing.

HYDRAULIC PRESSURES

1. The **ALLIED** winch requires hydraulic pressures in a range from 240 to 280 p.s.i. Below this range will now allow the free spool function to operate correctly and above the range could effect the winch's sealing capacity.

FLOWS

1. **ALLIED** requires a minimum hydraulic flow of 3 gallons/minute when the winch is operating. Any additional fluid should be relieved into the system's hydraulic reservoir.



NOTE: The winch requires a minimum of .5 TO 1 gpm flow at 20 psi to the lube lines anytime the engine is running.

SPRAG ROTATION

Make a check of the operation of the sprag before you connect the input prop shaft. Apply air to the input clutch. With clutch engaged, turn the input flange several revolutions in the normal direction of rotation. See that the drum rotates so as to wind the cable over the top of the drum. The winch drivetrain should move smoothly and evenly. Listen for any unusual noises.

	INPUT	RING GEAR LOCATION	SPRAG ROTATION
W SERIES	Clockwise	Toward Cover	Counter Clockwise
	Counter Clockwise	Away from Cover	Clockwise
WD SERIES	Clockwise	Away from Cover	Counter Clockwise
	Counter Clockwise	Toward Cover	Closewise

SPIRAL BEVEL AND HYPOID TOOTH BEARING CONTACT CHART



ALL CONTACT BEARINGS SHOWN BELOW ARE ON **RIGHT HAND** SPIRAL RING GEAR — THE DRIVE IS ON THE CONVEX SIDE OF THE TOOTH.




FIG. 1

TYPICAL PREFERRED BEARING ON BOTH SIDES OF TOOTH WHILE UNDER A LIGHT LOAD.




FIG. 2

TOE BEARING ON BOTH SIDES OF TOOTH — GEAR SET NOISY. TO MOVE BEARING TOWARD HEEL, INCREASE BACKLASH WITHIN LIMITS BY MOVING GEAR AWAY FROM PINION.




FIG. 3

HEEL BEARING ON BOTH SIDES OF TOOTH — GEARSET NOISY AND COULD RESULT IN EARLY GEAR FAILURE. TO MOVE BEARING TOWARD TOE, DECREASE BACKLASH WITHIN LIMITS BY MOVING GEAR TOWARD PINION.




FIG. 4

LOW BEARING ON GEAR AND HIGH BEARING ON PINION. CORRECT BY PULLING PINION AWAY FROM GEAR (INCREASE MOUNTING DISTANCE.)





FIG. 5



HIGH BEARING ON GEAR AND LOW BEARING ON PINION. CORRECT BY MOVING PINION IN TOWARD GEAR (DECREASE MOUNTING DISTANCE.)



BACKLASH

BACKLASH SHOULD BE MEASURED WITH A DIAL INDICATOR RIGIDLY MOUNTED WITH THE STEM PERPENDICULAR TO THE TOOTH SURFACE AT THE EXTREME HEEL.

SPIRAL BEVEL AND HYPOID TOOTH BEARING CONTACT CHART



ALL CONTACT BEARINGS SHOWN BELOW ARE ON **LEFT HAND** SPIRAL RING GEAR — THE DRIVE IS ON THE CONVEX SIDE OF THE TOOTH.




FIG. 1

TYPICAL PREFERRED BEARING ON BOTH SIDES OF TOOTH WHILE UNDER A LIGHT LOAD




FIG. 2

TOE BEARING ON BOTH SIDES OF TOOTH — GEAR SET NOISY. TO MOVE BEARING TOWARD HEEL, INCREASE BACKLASH WITHIN LIMITS BY MOVING GEAR AWAY FROM PINION.




FIG. 3

HEEL BEARING ON BOTH SIDES OF TOOTH — GEARSET NOISY AND COULD RESULT IN EARLY GEAR FAILURE. TO MOVE BEARING TOWARD TOE, DECREASE BACKLASH WITHIN LIMITS BY MOVING GEAR TOWARD PINION.




FIG. 4

LOW BEARING ON GEAR AND HIGH BEARING ON PINION. CORRECT BY PULLING PINION AWAY FROM GEAR (INCREASE MOUNTING DISTANCE.)






FIG. 5

HIGH BEARING ON GEAR AND LOW BEARING ON PINION. CORRECT BY MOVING PINION IN TOWARD GEAR (DECREASE MOUNTING DISTANCE.)



BACKLASH

BACKLASH SHOULD BE MEASURED WITH A DIAL INDICATOR RIGIDLY MOUNTED WITH THE STEM PERPENDICULAR TO THE TOOTH SURFACE AT THE EXTREME HEEL.



**GRADE 8
TORQUE SPECIFICATIONS**

Dry Type Threads

Lubricated or Plated Type Threads

COARSE THREADS	Dry Type Threads			Lubricated or Plated Type Threads		
	lbf. ft.	kgm f/m	N.M.	lbf.ft.	kgm f/m	N.M.
1/4" - 20	11 - 12	1.5	15 - 16	8 - 10	1	11 - 13
5/16" - 18	20 - 28	3 - 4	27 - 38	26 - 30	3.5 - 4	35 - 40
3/8" - 16	44 - 48	6 - 6.5	60 - 65	33 - 36	4.5 - 5	45 - 49
7/16" - 14	70 - 77	10 - 11	95 - 104	52 - 57	7 - 8	71 - 77
1/2" - 13	106 - 117	14 - 16	144 - 158	80 - 88	11 - 12	109 - 119
9/16" - 12	153 - 168	21 - 23	208 - 228	115 - 127	16 - 18	156 - 172
5/8" - 11	212 - 233	29 - 32	288 - 316	159 - 175	22 - 24	216 - 237
3/4" - 10	376 - 414	52 - 57	510 - 561	282 - 310	39 - 43	393 - 420
7/8" - 9	606 - 667	84 - 92	822 - 904	455 - 501	63 - 69	617 - 679
1" - 8	909 - 1000	126 - 138	1233 - 1355	682 - 750	94 - 104	925 - 1016
1-1/8" - 7	1288 - 1417	178 - 196	1746 - 1921	966 - 1062	135 - 146	1310 - 1441
1-1/4" - 7	1817 - 1999	251 - 277	2464 - 2710	136 - 1496	188 - 207	1844 - 2027

FINE THREADS	Dry Type Threads			Lubricated or Plated Type Threads		
	lbf. ft.	kgm f/m	N.M.	lbf.ft.	kgm f/m	N.M.
1/4" - 28	13 - 14	2	18 - 19	10 - 13	1 - 2	14 - 17
5/16" - 24	23 - 28	2 - 4	31 - 38	18 - 25	2.5 - 3.5	25 - 33
3/8" - 24	49 - 54	7 - 7.5	67 - 73	37 - 41	5 - 5.5	50 - 55
7/16" - 20	78 - 86	11 - 12	106 - 116	58 - 64	8 - 9	79 - 86
1/2" - 20	120 - 132	16 - 18	163 - 179	90 - 99	12.5 - 13.5	122 - 134
9/16" - 18	171 - 188	24 - 26	232 - 255	128 - 141	18 - 19	174 - 191
5/8" - 18	240 - 264	33 - 36	326 - 258	180 - 198	25 - 27	244 - 268
3/4" - 16	420 - 262	58 - 64	570 - 626	315 - 247	44 - 48	427 - 470
7/8" - 14	668 - 735	92 - 102	906 - 996	501 - 550	69 - 76	679 - 745
1" - 12	995 - 1096	137 - 150	1359 - 1486	746 - 821	103 - 113	1012 - 1613
1-1/8" - 12	1445 - 1590	200 - 220	1960 - 2155	1083 - 1191	150 - 165	1469 - 1613
1-1/4" - 12	2012 - 2213	278 - 305	2728 - 2997	1509 - 1660	208 - 229	2046 - 2250



**GRADE 5
TORQUE SPECIFICATIONS**

Dry Type Threads

Lubricated or Plated Type Threads

COARSE THREADS	Dry Type Threads			Lubricated or Plated Type Threads		
	lbf.ft.	kgm f/m	N. M.	lbf.ft.	kgm f/m	N. M.
1/4" - 20	7 - 8	1	10 - 11	8 - 10	1	11 - 13
5/16" - 18	14 - 18	2 - 2.5	19 - 24	10 - 15	1 - 2	13 - 20
3/8" - 16	31 - 34	4 - 4.5	42 - 46	23 - 25	3 - 4	31 - 34
7/16" - 14	49 - 54	7 - 8	66 - 73	37 - 41	5 - 6	50 - 55
1/2" - 13	75 - 83	10 - 11	102 - 112	57 - 63	8 - 9	77 - 85
9/16" - 12	109 - 120	15 - 16	148 - 162	82 - 90	12 - 13	111 - 122
5/8" - 11	150 - 165	21 - 23	204 - 223	113 - 124	16 - 17	152 - 168
3/4" - 10	266 - 293	37 - 40	360 - 397	200 - 220	28 - 30	271 - 298
7/8" - 9	394 - 433	54 - 60	535 - 586	296 - 326	41 - 45	402 - 441
1" - 8	591 - 649	82 - 90	802 - 879	443 - 489	61 - 67	601 - 663
1-1/8" - 7	794 - 873	110 - 121	1077 - 1183	596 - 656	82 - 90	808 - 889
1-1/4" - 7	1120 - 1232	155 - 170	1519 - 1670	840 - 924	116 - 128	1139 - 1252



GRADE 5


TORQUE SPECIFICATIONS

Dry Type Threads

Lubricated or Plated Type Threads



FINE

THREADS	Dry Type Threads			Lubricated or Plated Type Threads		
	lbf. ft.	kgm f/m	N.M.	lbf. ft.	kgm f/m	N.M.
1/4" - 28	9 - 10	1	12 - 13	9 - 10	1	12 - 13
5/16" - 24	17 - 22	2 - 3	23 - 29	16 - 20	2 - 3	21 - 27
3/8" - 24	35 - 39	4 - 5	48 - 53	26 - 29	3 - 4	35 - 39
7/16" - 20	55 - 61	7 - 8	75 - 83	41 - 45	5 - 6	56 - 61
1/2" - 20	85 - 94	12 - 13	116 - 127	64 - 70	9 - 10	87 - 95
9/16" - 18	121 - 133	17 - 18	164 - 180	91 - 100	12 - 13	124 - 135
5/8" - 18	170 - 187	23 - 26	231 - 253	128 - 141	18 - 19	174 - 191
3/4" - 16	297 - 327	41 - 45	403 - 443	223 - 245	31 - 33	303 - 332
7/8" - 14	434 - 477	60 - 66	589 - 646	326 - 359	45 - 49	442 - 486
1" - 12	646 - 711	89 - 98	876 - 712	484 - 534	66 - 73	657 - 724
1-1/8"	891 - 980	123 - 135	1208 - 1328	668 - 735	92 - 101	906 - 996
1-1/4" - 12	1240 - 1364	171 - 189	1682 - 1849	931 - 1024	129 - 132	1262 - 1387





8620—CARB. HARDEN & GRIND

OIL SEAL SLEEVE



OIL SEAL DRIVER






CONTROL VALVE

Item	Description	Qty.
1	Centering spring retaining washer	1
2	Valve stop spacer.....	1
3	Centering spring.....	1
4	Centering spring retainer.....	1
5	Control valve body	1
6	Detent ball	1
7	Detent spring.....	1
8	Spring retaining washer snap ring.....	1
9	Valve spool oil seal	1
10	Valve spool.....	1


PARTS IDENTIFICATION

CONTROL VALVE



Item	Description	Qty.
1	Plug (for shipping only)	-
2	Plug (for shipping only)	-
3	Bolt, mounting, valve cover	8
4	Lkwsr, mounting, valve cover.....	8
5	Cover, valve body	1
6	Spring, detent.....	1
7	Ball, detent	1
8	Gasket, valve body cover.....	1
9	Seal, oil, valve spool	1
10	Ring, snap, spring washer.....	1
11	Washer, spring retaining	1
12	Spacer, valve stop.....	1
13	Spring, centering	1
14	Retainer, centering spring	1
15	Spool, valve.....	1
16	Body, control valve.....	1
17	Nut, regulating spool stop	1
18	Washer, retaining.....	1
19	Spring, regulating.....	1
20	Spacer, regulating spool	1
21	Sleeve, regulating	1
22	Spool, regulating	1
23	Retainer, centering spring.....	1
24	Ring, snap, centering spring retainer	1
25	Spring, centering.....	1
26	Stop, valve	1
27	O-Ring, valve stop.....	1
28	Ring, snap, valve stop.....	1



TS-7404



WINCH CABLE DRUM DRIVE SHAFT AND CLUTCH 400 SERIES WINCHES

Item	Description	Qty.	Item	Description	Qty.
201	Tag, warning.....	1	242	Seal, oil, drum hub bearing retainer	1
202	Screw, mounting, tag.....	2	243	Hub & washer assy	1
203	Set Screw	1	244	Ring, retaining, clutch hub.....	1
204	Spring, lock, adjusting bolt	1	245	Disc, clutch - outer.....	18
205	Lock, bolt, adjusting.....	1	245A	Disc, clutch - outer.....	19
206	Wear, button, free spool spring	1	246	Spring, separator, free spool clutch.....	12
207	Spring, adjusting free spool, bolt.....	1	247	Disc, clutch - inner	16
208	Bolt, adjusting, free spool	1	247A	Disc, clutch - inner	18
209	Bolt, mounting, bearing cup.....	6	248	Bolt, mtg., cable drum support	8
210	Lkwshr., mounting, bearing cup	6	249	Lkwshr, mtg., cable drum support	8
211	Cap, bearing, clutch release support.....	1	250	Seal, oil, drum hub	1
212	Gasket, clutch release support bearing cap	1	251	Ring, snap, bearing	1
213	Ring, piston drum release support	1	252	Bearing, hub, cable drum	1
214	Ring, retaining, bearing	1	253	Support, cable drum	1
215	Bearing, cable drum support	1	254	O-Ring, cable drum	1
216	Plug, housing.....	1	255	Ring, snap, cable drum support	1
217	Bolt, mtg., cable drum cover.....	10	256	Shaft, cable drum support	1
218	Lkwshr., mtg., cable drum cover	10	257	Bearing, drive shaft front	1
219	Cover, cable drum	1	258	Gear, cable drum drive	1
220	Seal, oil, cable drum cover	1	259	Bearing, drive shaft rear	1
221	Sleeve, wear (See Item 225).....	1	260	Ring, retaining, front bearing	1
222	Split ring, clutch shaft support	2	261	Drain hose assy.....	1
223	Bolt, mtg., cable drum to support	8	262	Adapter, drain hose	2
224	Lkwshr, mtg., cable drum to support	8	263	Case, winch.....	1
225	Support, cable drum (Incl. 221)	1	263A†	Nameplate	1
226	Spring, clutch drive - outer	6	263B†	Screw, nameplate.....	2
227	Spring, clutch drive - inner.....	6	264	Ring, locating, rear bearing	1
228	Piston, drum release clutch	1	265	Gasket, cable drum drive shaft cover	1
229	Seal, clutch shaft & release plate	1	266	Tube, drive shaft oil	1
230	O-Ring, piston	2	267	Plug, pipe, cable drum drive shaft cover	1
231	Seal, drum release support	2	268	Cover, cable drum drive shaft	1
232	Plug, pipe, clutch shaft	1	269	Lkwshr, mtg., drive shaft cover.....	6
233	Clutch shaft & release plate assy (Incl.232)	1	270	Bolt, mtg., drive shaft cover	6
234	Plug, piston bore	1	271	Nut, hex 3/8", steel, unf.....	2
235	O-Ring, piston bore plug	1	272	Lkwshr, 3/8".....	2
236	Ring, retaining, piston bore plug.....	1	273	Stud, 3/8" x 1-9/16".....	2
237	Bolt, mtg., cable drum to hub	8	274	Retainer, cable, 400 Series	1
238	Lkwshr, mtg., cable drum to hub	8	275	Screw, countersunk head, 400 Series.....	2
239	Sleeve, wear, cable drum hub support.....	1	276	Plug, check.....	1
240	Support, cable drum hub (Incl.239)	1	277	Lkwshr, 1/4".....	2
241	Drum, cable	1			

† not illustrated



TS-12285

WINCH - INPUT CLUTCH, PINION SHAFT AND RING GEAR FOR THE 400 SERIES WINCH

Item	Description	Qty.	Item	Description	Qty.
1	Air breather, check valve assy. (Incl.2)	1	34	Ring, clutch, bearing	1
2	Included in Item 1	1	35	Ring, snap, bearing	1
3	Seal, clutch piston - inner	1	36	Bearing, clutch - rear	1
4	Piston, clutch	1	37	Ring, snap	1
5	Ring, piston - outer	1	38	Spacer, spring	1
6	Plug, input shaft	1	39	Retainer, bearing	1
7	Input shaft & drum assy. (Incl. 6)	1	40	Spring, piston, bearing	1
8	Gasket, input bearing	1	41	Ring, snap, plate	1
9	Cap, input bearing	1	42	Plate, disc, bearing	1
10	Bearing, input	1	43	Disc, clutch - inner	6
11	Gasket, input	1	44	Disc, clutch - outer	6
12	Retainer & oil seal (Incl.13)	1	45	Lkwshr, mtg.	6
13	Seal, oil	1	46	Bolt, mtg, cover	6
14	Flange, input	1	47	Cover, pinion brake (Incl. 47)	1
15	O-ring, flange	1	48	Pin, dowel	1
16	Washer, flange	1	49	O-ring, cover	2
17	Nut, flange	1	50	Ring, brake	1
18	Bolt, mtg, retainer	4	51	Ring, piston	1
19	Lkwshr, mtg.	4	52	Disc, brake	1
20	Nut	6	53	Housing, brake	1
21	Lkwshr, mtg.	6	54	Nut, pinion shaft	1
22	Cap stud	6	55	Hub, pinion shaft	1
23	Race, shaft, ring	1	56	Bearing, assy. - cup	1
24	Lock, race	1	56A	Bearing, race - cone	1
25	Lkwshr, mtg.	1	57	Race, spring - inner	1
26	Bolt, mtg, lock	1	58	Retainer, sprag	1
27	Ring, piston	2	59	Sprag assy.	1
28	Ring, snap	1	60	Bearing assy.	1
29	Bearing, input - rear	1	61	O-ring - front	1
30	Ring, snap	1	62	Shim, outer - .004	‡
31	Bearing, clutch, driven	1	62A	Shim, outer - .007	‡
32	Ring, snap	1	62B	Shim, outer - .010	‡
33	Gear, hub (41T)	1	62C	Shim, outer race - .020	‡

‡ As required

WINCH - INPUT CLUTCH, PINION SHAFT AND RING GEAR FOR THE 400 SERIES WINCH Cont'd.


Item	Description	Qty.	Item	Description	Qty.
63	Sprag outer race	1	90	Bolt, mtg, shaft.....	2
64	O-ring, sprag outer race	1	91	Lkwshr, mtg	2
65	Gasket, outer cover.....	1	92	Bolt, mtg, cover.....	4
66	Cover, pinion shaft	1	93	Lkwshr, mtg	4
67	Lkwshr, mtg.....	8	94	Bearing, pinion.....	1
68	Bolt, mtg, cover	8			
69	Gear, pinion drive (67T)	1			
70	Tube, lubrication	1			
71	Sleeve, tube	1			
72	Lockwasher	1			
73	Bolt.....	1			
74	O-ring, shaft	1			
75	Shaft, ring gear	1			
76	Cone, ring gear	1			
77	Cup, ring gear - inner	1			
78	Ring gear and pinion set	1			
78A	Hub, ring gear (19T).....	1			
78B	Bolt, mtg, ring gear.....	12			
79	Cup, ring gear - outer.....	1			
80	Cone, ring gear - outer.....	1			
81	O-ring, shaft	1			
82	Shim, shaft - .004.....	‡			
82A	Shim, ring gear shaft - .007.....	‡			
82B	Shim, shaft - .010.....	‡			
83	O-ring, cover	1			
84	Shim, cover - .004.....	‡			
84A	Shim, cover - .007.....	‡			
84B	Shim, cover - .010.....	‡			
85	Cover, ring gear	1			
86	Stud, mtg, cover.....	1			
87	Lkwshr, mtg, cover.....	5			
88	Nut, mtg. cover.....	1			
89	Plug, cover	1			

‡ As required

NOTES



CHECK BEFORE ASS'Y.
OF SPRING PACK

6.691
6.768



1. Assemble seal flush with face casting as shown.
2. Assemble oil seal after winch drum is installed in winch housing.
3. Torque nut to 64-70 Lbs. Ft.
4. Torque bolts to 85-100 Lbs. Ft.
5. Shim to adjust ring gear bearings to 50-60 Lbs. in. of rolling torque.
6. Shim as required to set ring and pinion contract and backlash.
7. Shim to adjust bearings - 15 Lbs. in. to 25 Lbs. in. pinion rolling torque.
8. Tighten flange nut to 175-200 Lbs. Ft.
9. Torque to 41-45 Lbs. Ft.
10. Input clutch - 6 outer steel plates, 6 inner bronze plates, alternately assembly starting with outer steel plate.
11. Press bearing to this dimension, $\frac{.000}{.020}$
12. Apply grease on the cable drum plunger puck and bearing cap area that contains it.
13. Assemble self locking plug with 30-40 Lbs. Ft. of torque.
14. Seal must be installed as shown.
15. Assemble seal flush with face of casting as shown.
16. 2-split rings.

17. W 7 WD-310 shown here.
 18. Press wear sleeve with load not to exceed 200 Lbs.
 19. Assemble ring gear cover with inspection hole above center.
 20. Clockwise Pinion. Shaft freewheel direction.
 21. Counter Clockwise Pinion. Shaft freewheel direction.
 22. Section X-X Spring Grouping.
 23. 2 groups of springs required. 6 springs per group as shown in section X-X. When tolerances require shimming of the clutch pack, assemble the shim in line with the center and bottom shim for proper spring compression.
 24. Outside mounted ring gear backlash should be measured thru ring gear cover access hole with a dial indicator rigidly mounted with the stem perpendicular to the ring gear mounting screws or toe of pinion. The amount should vary from .006 to .011. See tooth contract chart.
- NOTE: If mounting information is etched on ring gear, this takes precedence over chart data.
25. Install drain plug in bottom of winch housing to this dim. shown out of position.



PARTIAL VIEW OF FREE SPOOL CLUTCH ASSEMBLY

Alignment between mounting bolt in cable drum release support and timing groove in drum release clutch piston must not exceed .06 either side of center line.

Bolt alignment into cable drum must be accomplished without pry bar or other rotating force.

DANGER

THIS CLUTCH IS SPRING-LOADED.
 READ THE MAINTENANCE MANUAL SUPPLIED
 WITH THIS MACHINE BEFORE REMOVING THIS
 COVER.

View A-A

ASSEMBLY OF FREE SPOOL CLUTCH

To check assembled free spool clutch:


1. Apply air pressure, 100 PSI max., to center hole "A" in end of shaft. Air must not come out .500 from same end of shaft.
2. Apply air pressure to radial hole "B". Air must come out of center hole "A".
3. Repeat Step 2 and place finger over center hole. Air must not come out at any part of assembly. If assembly does not pass this test, disassemble and check for cut lip seals, or lip seals placed backward.

GENERAL NOTES

1. Assemble to parts list as to flange size, gear ratios and input rotation.
2. All lead-in chambers for oil seals, piston rings and "O" rings must be smooth and free from burns. Inspect at assembly.
3. Lubricate all piston rings and oil rings at assembly.
4. Use Permatex and Crane Sealer only where specified.
5. Apply a very thin coat of Permatex No. 2 to O.D. of all oil seals before assembly.
6. Apply Crane Sealer to all pipe threads.
7. After assembly of parts using Permatex No. 2, there must not be any free or excess material that could enter the oil circuit.
8. Lubricate all bearings with Type "A" oil in assembly.
9. After assembling seating rings into grooves, coat with Type "A" oil.
10. Apply Permatex to all studs prior to assembly.
11. Install both cap mounting screws when seating ring gear cover.
12. Insure seating of bearings and related parts by seating ring gear cover without using shims.
13. "O" rings should be assembled after shimming of bearings to prevent damage to various parts.
14. Gear should be rotated and cover rapped each time assembly is made to insure the proper alignment of bearings.
15. Measure 6.691/6.768 clutch drum spring plate dimension and record actual dimension on assembly line card.
16. Prior to building cable drum clutch, remove all residual storage oil from separator plates.
17. Stamp name plate at assembly.

WHEN TOLERANCES REQUIRE SHIMMING OF THE CLUTCH PACK, ASSEMBLE THE SHIM INLINE WITH THE CENTER AND BOTTOM SHIM FOR PROPER SPRING COMPRESSION.

2 - GROUPS OF SPRINGS REQUIRED 6 - SPRINGS PER GROUP AS SHOWN.



* Shimming Plate Not Included.


FREE SPOOL CLUTCH			
MODEL	"A"	"B"	NO PLATES*
W&WD-410	ONE	8 STEEL	19 STEEL
W&WD-411	STEEL	9 FIBER	18 FIBER
W&WD-412	PLATE		

Alternately assemble plates, see parts list, starting with steel outer plate. Shim at final assembly with steel outer plates per parts list to maintain 6.691 - 6.768 dim.

CHART 1		
MODEL	INPUT FLANGE ROTATION	PINION SHAFT FREEWHEEL ROTATION
W	Clockwise	Counter Clockwise
W	Counter Clockwise	Clockwise

POWER FLOW

(WITH INSIDE MOUNTED RING GEAR)




WINCH IN POSITION

■ PRESSURE ON □ ROTATING PARTS ■ SLIDING PARTS

POWER FLOW


(WITH OUTSIDE MOUNTED RING GEAR)



WINCH IN POSITION

■ PRESSURE ON □ ROTATING PARTS ▨ SLIDING PARTS


POWER FLOW



HOLD POSITION

■ PRESSURE ON □ ROTATING PARTS ■ SLIDING PARTS

POWER FLOW



FREE SPOOL POSITION

■ PRESSURE ON □ ROTATING PARTS ▨ SLIDING PARTS

NOTES

